




Video Intercom App Guide

This document describes how to use the Video Intercom app.
Please read this document together with the Operating Instructions provided with your Video Intercom.

Introduction

You can install the **[Video Intercom]** app (Video Intercom application for smartphone) on your mobile devices, and use your mobile devices to access features of your Panasonic main monitors.

- See page 4 for information about how to get started.
- The following illustrates how the main monitor can connect to your devices over Wi-Fi and over the Internet. Note that a wireless router is required to connect your mobile device to the main monitor.



Main features

- Answering doorphone calls (page 9)
- Monitoring sound and images from a doorphone (page 9)
- Receiving notifications from sensors connected to the main monitor (page 11)
- Opening doors by operating electric locks that are connected to the main monitor (page 11)
- Configuring the main monitor to send email notifications (page 12)

Supported devices

Please check the latest information at the following supported page.

<https://panasonic.net/cns/pcc/support/intercom/smartphone/>

- **Panasonic Video Intercoms**
Model numbers VL-SVN511, VL-MVN511
- **Compatible mobile devices (As of October, 2019)**
 - iPhone and iPad (iOS 9.0 and later)
 - Android™ devices (Android 4.0 and later)

Note:

- Certain features may not be available depending on the model or operating system version of your mobile device.
- Operations and screens may vary depending on the mobile device's operating system, operating system version, and model.
- The term "mobile device" is used in this document to refer to any smartphone or tablet that is compatible with the app.

1. Getting started

Getting started

- 1.1 Preface4
- 1.2 [Video Intercom] app preparation
overview4
- 1.3 Updating the [Video Intercom] app
overview5
- 1.4 Starting the [Video Intercom] app6
- 1.5 Notifications8

2. Using the app

Using the app

- 2.1 Answering doorphone calls9
- 2.2 Monitoring the doorphone9
- 2.3 Features available when talking on a
doorphone call or monitoring10
- 2.4 Receiving a doorphone call while talking on
another doorphone call or while
monitoring11
- 2.5 Using alarm notifications11
- 2.6 Operating electric locks11
- 2.7 Configuring the email notification
feature12
- 2.8 Managing wireless access points14

3. Settings

Settings

- 3.1 Settings menu15

4. General Information

General Information

- 4.1 Troubleshooting17
- 4.2 Error Messages20
- 4.3 Trademarks and Copyright
Information20

1.1 Preface

About the [Video Intercom] app

- Product screens and illustrations used in this document are for reference only, and may differ from the actual product.
- The content of this document is current as of October, 2019.
- Operations and available features may differ from those explained in this document, depending on the mobile device's operating system, operating system version, and model. In some cases, the app may not be able to be used.
- The app may not be able to be used depending on other apps that are running on the same mobile device. In particular, apps that allow phone or voice calls may interfere with this app.
- The design and specifications of the app are subject to change without notice and may differ from the content in this document.
- The app can only be used when your mobile device and the main monitor are connected to the same network. Throughout this document, we use the expression "the same wireless router" to mean "the same network".
- Your mobile device will not receive notifications or doorphone calls if the app is not running. (The **[Video Intercom]** app runs in the background to receive incoming calls and notifications even when the **[Video Intercom]** app is not being operated.)
- Energy-saving mode (iPhone and iPad only)
In the following situations, the energy-saving mode can stop the operations (communications) of the **[Video Intercom]** app and conserve battery usage.
 - When the mobile device is a certain distance (approx. 100 m to 200 m radius) or more away from the main monitor and out of range of the wireless LAN

When using energy-saving mode, select to always allow access to location information for the **[Video Intercom]** app and set the installation location of the main monitor. (See page 16.)

Please note that Panasonic does not obtain the location information.

- Location information (Android 6.0 and later, iOS 13 and later)
The **[Video Intercom]** app operates with the main monitor and mobile device connected to the same wireless LAN (SSID). If a message about allowing access to location information is displayed to obtain wireless LAN information, select to always allow access. The operations differ depending on the mobile device. Operations may not be performed correctly if access to location information is not allowed. Please note that Panasonic does not obtain the location information.

1.2 [Video Intercom] app preparation overview

- 1 Connect the main monitor to your wireless router.
 - Refer to the operating instructions included with the main monitor for information about connecting to wireless routers.
- 2 Enable your mobile device's Wi-Fi feature and connect your mobile device to your wireless router.
 - Refer to the operating instructions included with your mobile device for information about connecting to wireless routers.
- 3 Download and install the **[Video Intercom]** app.
 - Visit the following website for more information.



<https://panasonic.net/cns/pcc/support/intercom/smartphone/>

- 4 Register your mobile device to the main monitor.
 - See 1.2.1 Registering your mobile device to the main monitor (page 5).

1.2.1 Registering your mobile device to the main monitor

1 Use your mobile device to perform the following.


1. Start the **[Video Intercom]** app by tapping its icon (shown below).
 - If a message about allowing access is displayed, allow access.



2. Read the displayed license agreement and tap **[Agree]**.

2 Use the main monitor to perform the following.

- Refer to the operating instructions included with the main monitor for information about operating the main monitor.
- Main monitor operations listed in this document use the VL-MVN511 operations as an example.

1. Top menu →  → .
2. Select **“Register/Cancel”** → .
3. Select **“Register”** → .
4. Select the mobile device registration number → .
 - Complete the remaining steps within 2 minutes.

3 Use your mobile device to perform the following.


1. Read the displayed message and tap **[Register]**.
 - A beep sounds from the main monitor when registration is completed.
 - Operate by following the on-screen instructions.
See Energy-saving mode (page 16).

4 Use the main monitor to perform the following.

1. Press **[OFF]**.

Cancelling your mobile device from the main monitor

If you do not plan on using the **[Video Intercom]** app any longer, we recommend cancelling your mobile device from the main monitor.

1. Top menu →  → .
2. Select **“Register/Cancel”** → .
3. Select **“Cancel”** → .
4. Select the mobile device registration number → .
5. Press **[OFF]**.

1.3 Updating the [Video Intercom] app overview

The **[Video Intercom]** app is constantly being improved and updated with new features. We recommend updating the app to keep up with the latest changes.

Note:

- Updates such as new features may not be available if the app is not updated.

1.3.1 Updating the [Video Intercom] app

When a notification about updating the app is received on the mobile device, follow the on-screen instructions to update the app.

1. Getting started

1.4 Starting the [Video Intercom] app

Starting the application

1. Start the [Video Intercom] app by tapping its icon (shown below).




- The top screen of the [Video Intercom] app is displayed (refer to the information below).

Navigating the screens

The screens shown here are examples from an Android device.


Top screen

Displayed when you start the app or exit the operation screen.



Operation screen

Displayed when you are receiving a doorphone call, talking on a doorphone call, or monitoring a doorphone.



- ① **App status icon (Android only)**
Displayed when the [Video Intercom] app is running and indicates the status of the app.
- ② **Monitor button**
Displays the operation screen.
- ③ **Settings button**
Displays the settings menu.
- ④ **Options menu icon**
Displays the options menu.







- ⑤ **Status display area**
See page 7.
- ⑥ **Image viewing area**
Displays the image from the doorphone.
- ⑦ **Display orientation button**
Switches between portrait (vertical) and landscape (horizontal) display modes. See page 10.
- ⑧ **Operation buttons**
Allow you to operate different features. The buttons that are displayed vary depending on current operation.

Returning to the previous screen

For Android devices, press your mobile device's "back" button.

For iPhone and iPad, tap .

Status display area

Display	Meaning
	Indicates which doorphone is calling you, which doorphone you are talking to, or which doorphone you are monitoring. ("1" and "2" indicate the device number, and "L" indicates the entrance lobby.)
	Indicates that you are monitoring the doorphone (page 9).
	Indicates that you are talking on a doorphone call (page 9).
	Indicates that image is displayed in zoom mode.
	Indicates that the doorphone's LED lights are on.
	Indicates that you are receiving a doorphone call (while you are already talking to or monitoring another doorphone).

1.5 Notifications

The **[Video Intercom]** app can notify you when you receive calls from doorphones (page 9) and when sensors connected to the main monitor are triggered (page 11). The app can notify you by playing a ringtone or notification sound, and by displaying a message.

Note:

- Notification features behave differently depending on the status of your mobile device and your mobile device's settings.

When a notification is displayed

Tap the notification (unlock the screen if necessary) to display the **[Video Intercom]** app's screen. You can then take appropriate action, such as answer the doorphone call (page 9) or read details about the alarm notification (page 11).

Note:

- You cannot change the ringtone used for the **[Video Intercom]** app's notifications.
- If the ringtone or notification sound plays but no notification is displayed, switch from the current app to the **[Video Intercom]** app manually.

Notes for Android device users



- If you are using another app when a doorphone call or alarm notification is received, your mobile device's screen switches automatically to the **[Video Intercom]** app's screen.
- **Notification sound**
A step-up tone is used for the notification sound (i.e., the sound plays quietly and gradually becomes louder).
- **Ringtone**
The doorphone ringtone plays at the same volume as your mobile device's ringtone (i.e., the ringtone used for phone calls).
- **Silent mode**
If your mobile device's silent mode is enabled, the notification sound will be played but the doorphone ringtone will not be played.

Notes for iPhone and iPad users

- If the **[Video Intercom]** app's screen is not displayed after unlocking your mobile device's screen, display the app manually (i.e., tap the app's icon in your mobile device's home screen, select it from the recent apps list, etc.).
- **Notification sound**
If the screen is locked or another app is in the foreground, notification features behave according to the Notifications Centre settings, found in your mobile device's **[Settings]** app.
If the **[Video Intercom]** app is in the foreground, a step-up tone is used for the notification sound (i.e., the sound plays quietly and gradually becomes louder).
- **Ringtone**
If the screen is locked or another app is in the foreground, the doorphone ringtone plays at the same volume as your mobile device's ringtone (i.e., the ringtone used for phone calls).
If the **[Video Intercom]** app is in the foreground, the doorphone ringtone plays at the same volume as your mobile device's playback volume for music and multimedia (i.e., you can adjust the volume by pressing your mobile device's volume buttons).
- **Silent mode**
If the screen is locked or another app is in the foreground, and if your mobile device's silent mode is enabled, the notification sound and doorphone ringtone will not be played.
If the **[Video Intercom]** app is in the foreground, the notification sound and doorphone ringtone play as explained above.

2.1 Answering doorphone calls

When the app receives a doorphone call, it plays a ringtone.




- 1 From the **[Video Intercom]** app's operation screen, tap .
 - If the app's operation screen is not displayed, display the **[Video Intercom]** app manually (i.e., tap the app's icon in your mobile device's home screen, select it from the recent apps list, etc.).
- 2 When finished, tap .

Note:

- You can talk for up to about 90 seconds.
- If your mobile device receives a phone call while you are talking on a doorphone call, the doorphone call is disconnected.

2.2 Monitoring the doorphone

You can monitor the sounds and images from the doorphone.

- 1 From the **[Video Intercom]** app's top screen, tap .
 - If there are multiple doorphones, select the desired doorphone.
- 2 Monitor the sound and image.
 - You can talk to the monitored party by tapping .
- 3 When finished, tap .

Note:

- The sound from your end is not heard at the doorphone.
- You can monitor for up to about 3 minutes.
- If your mobile device receives a phone call while you are monitoring a doorphone, monitoring ends.

Notes about doorphone audio


- When you begin talking on a doorphone call or monitoring a doorphone, the doorphone audio plays through your mobile device's audio output (receiver or speaker) according to the **[Speaker setting]** setting. This setting is available in the settings menu (page 15).
- While talking on a doorphone call or monitoring a doorphone, you can temporarily switch between the receiver and speaker by opening the options menu and selecting **[Speaker]** (page 10).
- When doorphone audio is played through your mobile device's speaker, the doorphone audio may cut out if there is background noise on your end. In this case, refer to the information above and switch to another audio output, or move to a quieter location.
- Certain mobile devices do not feature a receiver or a speaker. In this case, the **[Speaker setting]** setting is ignored.
- When a wired or Bluetooth headset is connected to your mobile device, that device is used as the audio output.

2. Using the app

2.3 Features available when talking on a doorphone call or monitoring

2.3.1 Switching the display orientation

Tap the display orientation button (①) in the image viewing area, or rotate your mobile device so that it is in landscape position (i.e., parallel to the ground) or portrait position (i.e., perpendicular to the ground).



Note:

- When you switch to landscape display mode, the operation buttons disappear and only the image display area is shown. In order to call a doorphone or perform certain operations, you must switch to portrait display mode.
- The ability to switching between portrait and landscape display modes by rotating your mobile device may not be available depending on the features of your mobile device.

2.3.2 Zoom, pan, and tilt

Zooming in and out (wide mode, zoom mode)

Double tap the displayed image to zoom in (zoom mode); double tap again to zoom out (wide mode).

Changing the area that is displayed (pan/tilt)


While using zoom mode, tap the desired area of the image.

2.3.3 Backlight compensation, lighting, and speaker settings

The following features are not available when using landscape display mode.


Configuring backlight compensation for the doorphone

Configure settings when an image is displayed or when talking on a doorphone call.

1. From the **[Video Intercom]** app's operation screen, tap  → **[Backlight compensation]**.
2. Tap **[-]** or **[+]** to adjust brightness.
 - Adjust the brightness while checking the displayed image.
 - To turn off backlight compensation, tap **[OFF]**.
 - Depending on the doorphone you are using, the adjustment buttons may be displayed as **[OFF]** and **[ON]**.


Turning the doorphone's LED lights on and off

Configure settings when an image is displayed or when talking on a doorphone call.


1. From the **[Video Intercom]** app's operation screen, tap  → **[Illumination]**.
2. Select **[ON]** or **[OFF]**, and then tap **[OK]**.

Changing the audio output



While talking on a doorphone call or monitoring, you can switch between the available audio outputs.

1. From the **[Video Intercom]** app's operation screen, tap  → **[Speaker]**.
2. Select the desired setting.
 - Available settings vary by your mobile device's settings, hardware configuration, etc.
 - This setting is used only for the current doorphone call or monitoring session. The next time you answer a doorphone call or start monitoring, the audio output selected for the **[Speaker setting]** setting will be used. You can change this setting in the setting menu (page 15).



2.4 Receiving a doorphone call while talking on another doorphone call or while monitoring

If you receive a doorphone call when you are already talking to or monitoring another doorphone, the app plays the ringtone and displays  in the status display area.

To monitor the new visitor

Tap  or  to end the current doorphone call or monitoring session and begin monitoring the new visitor.

To ignore the new doorphone call and continue the current doorphone call or monitoring session

Continue talking or monitoring; do not tap  or .

2.5 Using alarm notifications

When a sensor (such as a fire alarm) is triggered, the app can play a notification sound and displays a message. You can tap the **[Close]** or **[Stop]** button to dismiss the alarm notification.

Note:

- For information about notification sounds and how notifications are displayed, see page 8.
- If a sensor is triggered while you are talking on a doorphone call or receiving a doorphone call, the call is disconnected.
- The app will not receive doorphone calls while an alarm notification is displayed.

Dismissing an alarm notification

Alarm notifications are dismissed in the following situations.

- 3 minutes pass after the sensor was triggered.
- The sensor is no longer being triggered.
- You tap the **[Close]** or **[Stop]** button.

What is the difference between **[Close]** and **[Stop]**?

[Close]


- Used to temporarily dismiss an alarm notification.
- Displayed when the notification sound begins playing, then switches to **[Stop]** after 5 seconds.
- Stops the notification sound played by your mobile device; the notification sound played by the main monitor continues.

[Stop]

- Used to permanently dismiss an alarm notification.
- Displayed about 5 seconds after the notification sound begins playing.
- Stops the notification sound played by your mobile device and the main monitor.

2.6 Operating electric locks

If there are electric locks connected to the main monitor, you can use the app to unlock them while talking on a doorphone call or while monitoring.

1 While talking on a doorphone call or while monitoring, tap .

2 Tap **[OK]**.

- If there are multiple electric locks connected, select the desired electric lock.
- A confirmation screen is displayed when the electric lock has been unlocked.

2. Using the app

2.7 Configuring the email notification feature

The email notification feature can be used to send an image from the doorphone when someone presses the doorphone's call button.

- For more information about this feature, see the documentation included with the main monitor.
- These settings can be configuring using the main monitor, however, it is easier to configure them using the app.

2.7.1 Email notification feature configuration overview



Before configuring the email notification feature, gather the following information.

- **Sender email address:** This is the email address that is used for sending email messages from the main monitor. Note that mobile phone-exclusive addresses cannot be used.
- **SMTP server:** This is the name of the email server that is associated with the email address. It typically starts with "SMTP".
- **Port number:** This is the port number used to send email via the email server associated with the email address.
- **Security type:** This is the type of encryption used by the email server. The email notification feature supports [TLS], [SSL], and [None].
- **SMTP authentication:** This is the [Account name] and [Password] required by the email server in order to send email.

Note:

- Email messages may not be able to be received if they are treated as spam. Configure all receivers' email accounts and email client software so that email messages sent by the email notification feature can be received.
- Email messages may not be able to be sent depending on the condition of the network.
- All email notifications are sent to all registered email addresses. You cannot select certain email addresses to receive only certain types of email notifications.


2.7.2 Registering the email server

- 1 From the [Video Intercom] app's top screen, tap  → [Email notification settings] → [Registration].
- 2 Enter the required settings.
 - These settings are explained in 2.7.1 Email notification feature configuration overview.
 - For Android devices only
If you set [SMTP authentication] to [On], tap [Settings], and then enter the [Account name] and [Password] used for authentication.
- 3 Tap [Next] (Android devices) or  (iPhone, iPad) → [OK].
 - A test email message is sent to the specified email address. Confirm that the email message is received.


Confirming the email server settings

1. From the [Video Intercom] app's top screen, tap  → [Email notification settings] → [Confirmation/modification].
2. Confirm the settings, and then tap  or your mobile device's "back" button.

Changing the email server settings


1. From the [Video Intercom] app's top screen, tap  → [Email notification settings] → [Confirmation/modification].
2. Select the content you wish to change, and register by following the displayed instructions.

Deleting the email server settings


1. From the [Video Intercom] app's top screen, tap  → [Email notification settings] → [Deregistration].
2. Follow the displayed instructions and delete the email server settings.

2.7.3 Registering the notification email addresses


You can register up to 4 email addresses that will receive notifications.

- 1 From the **[Video Intercom]** app's top screen, tap  → **[Email notification settings]** → **[Email notification address]**.
- 2 Enter the email address by one of the following steps.
 - Repeat the steps listed below when entering multiple email addresses.



When selecting an email address saved in the contacts list on your mobile device

 - a. Tap  or **[+]** next to the email address entry bar.
 - b. Select an email address from the displayed contacts list.

When directly entering an email address




 - a. Tap the email address entry bar.
 - b. Enter the email address.
- 3 Tap **[Next]** or .
- 4 Confirm the message → **[Send]**.
 - A test-mail is sent to the specified email address.
- 5 Confirm that the message has arrived at the specified email address → **[Register]**.
 - The email address is registered and **[Email notification]** is enabled.

Deleting registered email address

1. From the **[Video Intercom]** app's top screen, tap  → **[Email notification settings]** → **[Email notification address]**.
2. Tap the entry bar of the email address you wish to delete, and then delete the entered email address.
3. Tap **[Next]** or .




2.7.4 Enabling and disabling the email notification feature

Email notifications are enabled when the email server and email addresses are registered in the main monitor. Use the following procedure if you want to disable all email notifications temporarily (such as when you are at home) or enable them again.

- 1 From the **[Video Intercom]** app's top screen, tap  → **[Email notification settings]** → **[Email notification]**.
- 2 Slide the switch to the desired position.
 - : Email notifications are enabled.
 - : Email notifications are disabled.

2.7.5 Selecting devices that trigger email notifications

You can select which devices can trigger email notifications.

- 1 From the **[Video Intercom]** app's top screen, tap  → **[Email notification settings]** → **[Notification selection]**.
- 2 Slide the switches to the desired positions for each device.
 - : The device can trigger email notifications.
 - : The device cannot trigger email notifications.

2. Using the app

Note:

- These settings apply to all registered email addresses.

2.8 Managing wireless access points

A wireless access point is a device that allows your mobile device to connect to a network via Wi-Fi. (In most situations, your wireless access point is your wireless router.) A wireless access point is identified by the SSID (wireless network name) that is assigned to it.

The app maintains a list of up to 10 wireless access points that it can use to connect to your main monitor. In the following situations, use the procedure described in 2.8.1 Adding wireless access points (Page 14) to add additional wireless access points to the list.

When the main monitor is connected to a wireless access point that has multiple SSIDs (wireless network names)

In this case, add each SSID of the wireless access point to the list. This allows the app to connect to the main monitor regardless of which SSID your mobile device is connected to.

When there are multiple wireless access points with different SSIDs placed throughout your house in order to create a single network with wide wireless range

In this case, add the SSID of each wireless access point to the list. This allows the app to connect to the main monitor as you move between different areas of your house.

Note:


- Wireless access points are identified by their SSIDs, therefore, you do not need to register additional wireless access points if they use the same SSID as a wireless access point that you have already registered.

2.8.1 Adding wireless access points


Automatically adding wireless access points

If your mobile device is connected to a new wireless access point (i.e., an access point whose SSID has not been added to the wireless access point list), the **[Video Intercom]** app prompts you to add the wireless access point. When **[Connected to a new wireless access point (SSID). Do you want to add it?]** is displayed when using the **[Video Intercom]** app, tap **[OK]**.


Manually adding wireless access points

1. Connect to the wireless access point that you wish to add.
2. Start the **[Video Intercom]** app.
3. From the **[Video Intercom]** app's top screen, tap  → **[Wireless access point]**.
4. Tap **[+]** displayed on the top-right corner of the screen.
5. Confirm the message → **[OK]**.

Confirming the list of wireless access points


1. From the **[Video Intercom]** app's top screen, tap  → **[Wireless access point]**.
 - The wireless access point list is displayed.




Deleting wireless access points

1. From the **[Video Intercom]** app's top screen, tap  → **[Wireless access point]**.
 - The wireless access point list is displayed.
2. Select the wireless access point that you wish to delete.
3. Confirm the message → **[OK]**.

3.1 Settings menu

This section explains the settings that are available in the settings menu and how to adjust the settings.

- 1 From the **[Video Intercom]** app's top screen, tap .
- 2 Select the desired item.
 - Repeat this step as necessary to navigate to the desired setting.
- 3 Adjust the settings as desired.
 - Refer to the following table when adjusting the settings.

Menu name and submenu		Description	Default
Email notification settings	Email notification address ^{*1}	Allows you to register the email addresses (up to 4) that can receive email notifications. See page 13.	—
	Email notification ^{*2}	Determines whether the email notification feature is enabled or disabled. When [Registration] and [Email notification address] are configured, this setting is automatically enabled (i.e., email notifications will be sent). See page 13.	Disabled
	Notification selection ^{*2}	Determines which devices can trigger email notifications.	All enabled
	Registration	Registers the sender's email server information. See page 12.	—
	Confirmation/modification ^{*1}	Allows you to confirm the sender's email server information, and edit it if necessary.	—
	Deregistration ^{*1}	Deletes the sender's mail server information.	—
Call settings		Determines whether the ringtone plays when you receive a doorphone call, and how often the ringtone plays.	Ringtone is enabled, and plays each time the doorphone's call button is pressed
Talk (monitor) volume control (Android devices only)		The mobile device's receiver volume for doorphone calls and monitoring is adjustable to 5 levels (+2 to -2).	0
		The mobile device's microphone volume for doorphone calls is adjustable to 5 levels (+2 to -2).	
Speaker setting		Determines whether your mobile device's speaker is used when talking on doorphone calls or when monitoring. <ul style="list-style-type: none"> • This setting has no effect if your mobile device does not have a speaker. 	Off 

3. Settings


Menu name and submenu	Description	Default
Energy-saving mode (iPhone and iPad only)	Use [Energy-saving mode] to make battery power last longer when you are away from home. To use this setting, set the installation location of the main monitor by following the on-screen instructions. Set the location information for the app to [Always Allow] . (Energy-saving mode operates by obtaining the locations of the main monitor and mobile device. Depending on factors such as the communication status of the mobile device and the accuracy of the location information service, the location of the main monitor may not be correctly displayed.) <ul style="list-style-type: none"> • If the location of the main monitor is changed, reconfigure the installation location. • For iOS 12 and earlier: When not using [Energy-saving mode], select [Turn off] and set location information to [Always Allow]. 	—
Automatic start app (Android devices only)	Determines whether the [Video Intercom] app starts automatically when you turn on your mobile device.	Enabled
Information	Allows you to view information such as the [Video Intercom] app version, the IP address of your mobile device, the status of the app's to the main monitor, the list of wireless access points, etc. Tap [Add/Delete] under [Wi-Fi connection] to add or delete wireless access points.	—
Register	Used in the situations listed below. <ul style="list-style-type: none"> – When re-registration to the main monitor is required. – When registering to a new main monitor. Select this item when registering your mobile device to a main monitor.	—
Wireless access point	Allows you to add and delete wireless access points. See page 14.	—
Help	Opens your mobile device's web browser and accesses the [Video Intercom] app support site. Visit the support site for the latest version of this document.	—
Exit (Android devices only)	Exits the [Video Intercom] app. <ul style="list-style-type: none"> • Use only when you do not plan on using the [Video Intercom] app, such as when you are out of the house. 	—

*1 This item is available only if the **[Registration]** settings are complete.

*2 This item is available only if the **[Registration]** and **[Email notification address]** settings are complete.

4.1 Troubleshooting

Wi-Fi (wireless LAN) connections

Problem	Cause & Solution
Cannot connect to the main monitor	<ul style="list-style-type: none"> Your mobile device is not registered to the main monitor. → Register your mobile device to the main monitor (page 5). The main monitor or your mobile device is not connected to the wireless router. → Make sure that the wireless router is turned on, and that the main monitor and your mobile device are within range of the wireless router. The main monitor and your mobile device are not connected to the same wireless router. → Make sure that the main monitor and your mobile device are connected to the same wireless router. The wireless settings of the main monitor or your mobile device are incorrect. → Reconfigure the wireless settings of the main monitor and your mobile device. Refer to the documentation included with your main monitor and mobile device if necessary. The SSID of the wireless router has changed since the last time you used the app, either because you changed it or because you replaced your wireless router with a new one. → Add the wireless access point to the wireless access point list (page 14). (Up to 10 wireless access points can be saved.)
Cannot connect to the main monitor even after adding the current wireless access point	<ul style="list-style-type: none"> Depending on the wireless router, your mobile device may not connect to the main monitor even after you added the wireless router. → Check which SSID is registered on the main monitor, and then use your mobile device's Wi-Fi settings to select the same SSID. How to check which SSID is registered on the main monitor <ol style="list-style-type: none"> Top menu →  → <input type="button" value="OK"/>. Select "Network" → <input type="button" value="OK"/>. Select "Current status" → <input type="button" value="OK"/>. Select "Wi-Fi information" → <input type="button" value="OK"/>. <p>→ For information about how to configure and connect to your wireless router, refer to the operating instructions included with the wireless router.</p>

Doorphone calls, doorphone monitoring

Problem	Cause & Solution
Cannot receive doorphone calls, notifications	<ul style="list-style-type: none"> The [Video Intercom] app is not running. → The app will not receive doorphone calls or notifications if it is not running. Start the app (page 6). The Wi-Fi feature of your mobile device is in sleep mode. → Change the settings so that sleep mode is turned off while the [Video Intercom] app is in use at home. If you are using battery-saving applications, make sure sleep mode does not activate. <p>iPhone and iPad</p> <ul style="list-style-type: none"> The mobile device is out of range of the wireless LAN or the location information is out of range. → After coming in range, tap the [Video Intercom] app to launch it.
Ringtones or notification sounds are not played	<ul style="list-style-type: none"> The vibrating mode is enabled. → Disable the vibrating mode. Ringtones are disabled. → Check the [Call settings] settings (page 15).

4. General Information

Problem	Cause & Solution
Sound is not played through the speaker when talking on a doorphone call or when monitoring	<ul style="list-style-type: none"> ● The audio settings are not set to play sound from the speaker. → Check the [Speaker setting] settings (page 15). ● Depending on the model of your mobile device, app audio may not be able to be played through the speaker.
Sound cuts out while talking using your mobile device's speakerphone	<ul style="list-style-type: none"> ● Noise in the surrounding area is causing your mobile device's speakerphone audio to cut out. → This is a characteristic of many speakerphones. Either use your mobile device in a quieter location, or switch from speaker to receiver (page 10).
Your voice cannot be heard by the visitor during a doorphone call	<ul style="list-style-type: none"> ● Make sure your mobile device's microphone is not covered by anything such as your fingers or face. <p>iPhone and iPad</p> <ul style="list-style-type: none"> ● The app may not have permission to access your mobile device's microphone. → Use your mobile device's [Settings] app to allow the app to access the microphone.
Sound from the doorphone cuts out, images from the doorphone freeze	<ul style="list-style-type: none"> ● The main monitor and mobile device are being used where the wireless LAN signal is weak. → Use both devices where the wireless signal from the wireless router is strong. Refer to the main monitor documentation for information about how to check the signal status between the main monitor and the wireless router. For the signal status between your mobile device and the wireless router, refer to the documentation included with your mobile device. ● The main monitor and mobile device are being used near devices that give off strong electrical interference such as a microwave. → Make sure that the main monitor is installed in a location free from electrical interference. → Move your mobile device to an area with less electrical interference. → Relocate the interference-causing device if possible. ● A Wi-Fi repeater is being used. → This may occur if your mobile device switches its Wi-Fi connection between the wireless router and the Wi-Fi repeater. Use your mobile device in a location where it does not switch its Wi-Fi connection, or relocate the Wi-Fi repeater. ● Multiple devices, such as computers and mobile devices, are connected to the wireless router and are being used simultaneously. → Do not use multiple devices simultaneously.
Certain features cannot be used Example: <ul style="list-style-type: none"> ● Using your mobile device's speaker as the audio output ● Switching between portrait and landscape display modes 	<ul style="list-style-type: none"> ● Depending on the mobile device (model or operating system), some features may not be available.

Email notification settings

Problem	Cause & Solution
Cannot receive the test email	<ul style="list-style-type: none"> ● The mail server settings and email address settings are incorrect. → Check the mail server (page 12) and email address (page 13) settings. If the settings are incorrect, change them.

Problem	Cause & Solution
Test email was received, but cannot receive email notifications	<ul style="list-style-type: none"> ● The power of the wireless router is off, or the main monitor is out of range of the wireless router. <ul style="list-style-type: none"> → Confirm that the power of the wireless router is on, and relocate the main monitor to where it is within range of the wireless router. ● [Email notification] is disabled. <ul style="list-style-type: none"> → Enable [Email notification] (page 13). ● Email notifications are disabled for [Notification selection]. <ul style="list-style-type: none"> → Enable [Notification selection] for the devices you wish to send notifications from (page 13). ● There is a problem with the network environment or the mail server. <ul style="list-style-type: none"> → Check the sender's email account for an "undelivered message" reply from the mail server.
Do not wish to receive email notifications (Temporarily disable notifications such as when at home)	<ul style="list-style-type: none"> ● Disable the [Email notification] setting (page 13).

Others

Problem	Cause & Solution
Battery on mobile device drains too quickly	<ul style="list-style-type: none"> ● When at home (i.e., when your mobile device is connected to your wireless router), the [Video Intercom] app is ready and waiting to receive doorphone calls even when you are using another app. The [Video Intercom] app, therefore, consumes battery power even when it does not appear to be in use. This is not a malfunction. <p>iPhone and iPad</p> <ul style="list-style-type: none"> ● The location information of the app is set to a setting other than [Always Allow] (page 16). <ul style="list-style-type: none"> → Set the location information to [Always Allow].
The product does not work with correct operations. The product does not work properly	<ul style="list-style-type: none"> ● Try restarting your mobile device.

4.2 Error Messages

Display	Cause & Solution
Cannot register Cannot connect to the main monitor. Enable Wi-Fi for this smartphone. Cannot connect to the main monitor. Check the Wi-Fi connection.	<ul style="list-style-type: none">● The wireless router's signal strength is poor. → Relocate your devices so that your mobile device and the main monitor are closer to your wireless router.● You did not complete the registration procedure within the specified time. → Make sure that the wireless router is turned on, that the main monitor and your mobile device are connected to your wireless router, and then try registering your mobile device to the wireless router again.● The Wi-Fi feature of your mobile device is turned off. → Turn your mobile device's Wi-Fi feature on.● Your mobile device is out of range of the wireless router. → Make sure that the wireless router is turned on, that the main monitor and your mobile device are connected to your wireless router, and then try registering your mobile device to the wireless router again.
Could not connect to the main monitor. Please check the power or Wi-Fi connection to the main monitor.	<ul style="list-style-type: none">● The main monitor is not connected to the wireless router. → Make sure that the wireless router is turned on, that the main monitor and your mobile device are connected to the same wireless router, and then try again.
Doorphone unavailable	<ul style="list-style-type: none">● There is a problem with the connection between the main monitor and doorphone. → Make sure that the doorphone is receiving power. → Make sure that there are no problems with the connection between the doorphone and the main monitor.
Cannot connect to the server. Check the settings.	<ul style="list-style-type: none">● Mail server settings are incorrect. → Change the settings as needed and try again (page 12).● The wireless router cannot connect to the Internet. → Make sure your wireless router is configured so that the devices connected to your wireless router can connect to the Internet.
Check the security type and SMTP authentication settings	<ul style="list-style-type: none">● Security settings are incorrect.● SMTP authentication settings are required, but are incorrect. → Change the settings as needed and try again (page 12).
Verify your account name or password	<ul style="list-style-type: none">● The [Account name] and/or [Password] settings used for SMTP authentication are incorrect. → Change the settings as needed and try again (page 12).
Connected to a new wireless access point (SSID). Do you want to add it?	<ul style="list-style-type: none">● The SSID of the wireless router has changed since the last time you used the app, either because you changed it or because you replaced your wireless router with a new one. → Add the wireless access point to the wireless access point list (page 14). (Up to 10 wireless access points can be saved.)

4.3 Trademarks and Copyright Information

Trademarks

- Wi-Fi is a registered trademark or a trademark of Wi-Fi Alliance.
- iPhone and iPad are trademarks of Apple Inc., registered in the U.S. and other countries.
- Android is a trademark of Google LLC.
- All other trademarks identified herein are the property of their respective owners.

Copyright information

- Parts of this product use open source software. Open source software is supplied based on the conditions of the Free Software Foundation's LGPL and other conditions.
Copyright indication and licensing information are available on the following website.

<https://panasonic.net/cns/pcc/support/intercom/smartphone/>

- The license agreement for this product is available on the following website.

<https://panasonic.net/cns/pcc/support/intercom/smartphone/>

- Parts of this product use data created by Copyrights Vision Co., Ltd.
© 2013-2014 Copyrights Vision Inc.

